


A1 User Manual

----Getting started




A1 User Manual.....	1
1 Introducing your phone.....	4
2 Key functions.....	5
3 Home screen and Application list.....	6
3.1 Notification and connection icons.....	7
3.2 Read notifications.....	7
4 SIM Card.....	8
5 Battery.....	8
5.1 Charge using a charger cable.....	9
5.2 Charge using a USB cable.....	9
5.3 Please read before proceeding.....	9
6 Memory Card.....	9
7 Power.....	9
8 Call functions.....	9
8.1 Make calls.....	9
8.2 Answer calls.....	10
8.3 End calls.....	10
8.4 Call and set up voicemail.....	10
9 Contacts.....	10
9.1 Add contacts.....	11
9.2 Display contacts.....	11
10 Gmail setup.....	11
11 Email setup.....	12
11.1 Add e-mail accounts.....	12
11.2 Delete e-mail accounts.....	13
12 Bluetooth setup.....	13
12.1 Prepare a Bluetooth wireless headset.....	13
12.2 Turn on the Bluetooth feature and pair with a headset.....	13
13 WI-FI.....	14
14 Emergency dialing.....	14
15 Caring for your phone.....	14
15.1 Making it last.....	14
15.2 Tips for safety.....	15

1 Introducing your phone




Home screen will extend beyond the width of the screen to provide more space, so that you can add icons and Widgets. Slide on the desktop With finger rapidly, you can skip to the extend Home screen left or right.



2 Key functions

Menu key	<p>Press to open a list of actions available on the current screen.</p> <p>Press and hold to see the menu shortcuts for that screen.</p> <p>The shortcuts will blink in place as you hold down the Menu key.</p>
Back key	Press to go back to the previous screen or to dismiss a dialog box or menu.
Send key	<p>Press to perform one of the following:</p> <p>Open recent call log</p> <ul style="list-style-type: none"> ● Call a contact when a contact name/number is highlighted ● Add another call (while on a call) ● Display ongoing call on the screen (if you have navigated to another application) ● Call the number when a phone number is highlighted (example while in the Browser)
End key	<p>When on a call, press to hang up.</p> <p>When not on a call:</p> <ul style="list-style-type: none"> ● Press and hold to power on/off the phone or put it into Home .
Track ball	<p>Roll the trackball to navigate left, right, up, and down.</p> <p>Press to select an item.</p>
Volume key	While receiving incoming call, press either (+) or (-) to silence the ringer.
Power on/off	<p>Press and hold to Power on/off;</p> <p>Press to lock screen and put the phone into sleep mode.</p>

3 Home screen and Application list



Tap any icon to start using the application.

Tap or drag the application tab with your fingertip to reveal/hide the application icons.































3.1 Notification and connection icons

Along the top of your screen is the status bar. On the left side, icons will appear, notifying you of new messages, upcoming calendar events, alarms, and more. On the right side of the status bar, you will see the connection status icons.

3.2 Read notifications

When you see a notification in the status bar, tap the bar and slide your finger down the screen to open the list of notifications.

- To open the notification, tap the item.
- To clear notifications, tap Clear notifications at the top of the notification window.
- To close the notification window, slide your finger up the screen.

	New e-mail message		Ringer is off (silent mode)
	New text or picture message		Ringer on vibrate only
	Problem with text or picture message delivery		Phone is on mute
	New instant message		GPS is on and is working
	New voicemail		Uploading / downloading
	Upcoming event		Content downloaded
	Alarm is set		GSM signal, roaming, no signal
	Song is playing		GPRS service connected, data flowing
	Data is syncing		SD card is full
	More (undisplayed) notifications		Wi-Fi service connected, network available
	Call in progress		Battery charge indicators (full, half-full, low, very low)
	Missed call		Battery is charging
	Call on hold		Wireless services are off
	Call forwarding is on		Bluetooth is on, Bluetooth device connected
	Speakerphone is on		No SIM card

4 SIM Card

Your Subscriber Identity Module (SIM) card identifies you to the wireless network. Your phone will not work without the SIM card.

To insert the SIM and battery:

1. Detach your SIM card.
2. Peel the back to cover off.
3. Slide the SIM card into the holder until it stops.
4. Insert the battery into the phone, and re-covered back.

5 Battery

You can charge your phone using the charger cable connecting to a wall power outlet or by using the USB cable connecting to your computer.

5.1 Charge using a charger cable

To charge, connect the small end of the charger cable to the micro-USB port on the bottom side of your phone. Plug the other end of the charger into a wall outlet.

5.2 Charge using a USB cable

To charge, connect the small end of the USB cable to the micro-USB port on the bottom side of your phone. Plug the other end of the USB cable to the USB port of your computer.

5.3 Please read before proceeding

The battery is not fully charged when you take it out of the box. Do not remove the battery pack when the phone is charging. There was an animation when off charging and a picture when battery is full. Your warranty is invalidated if you open or tamper with the phone's outer casing.

6 Memory Card

Your phone comes with a removable micro SD memory card (pre-installed) where you can store multimedia files, such as video clips, music tracks, sound files, images, and messaging data.

To install the memory card:

1. Open the phone back, unplug the battery, and find a memory card slot.
2. Insert the memory card slot.
3. Cover the metal protectively.
4. Insert the battery and replace the cover.

To remove the memory card, press the card in and release.

7 Power

To turn on the phone, press and hold the red End key.

8 Call functions

8.1 Make calls

1. From anywhere on your phone, press the green **Send** key.
2. Touch one of the following tabs:
 - Dialer: Touch the numbers on the screen and press the green **Send** key.
 - Call log: Touch an entry on the list to call.
 - Contacts: Touch the contact and tap the phone number to call.
 - Favorites: Touch the contact and tap the phone number to call.

8.2 Answer calls

To answer a call, press the green **Send** key.

8.3 End calls

To end the call, press the red **End** key.


8.4 Call and set up voicemail

1. From anywhere on your phone, press the green **Send** key.
2. Touch the dialer tab.
3. Touch and hold 1.
4. Follow the tutorial to set up voicemail.

9 Contacts

The contacts on your phone are synced with your Google account contacts stored on the Web. To view the contacts on your phone, press the Home key and touch Contacts. You can also press the green Send key and touch the Contacts tab.

Contacts belonging to a specific group (you can choose which group) are listed in the Contacts tab. Only those contacts you select as favorites are listed in the Favorites tab. If your contact is online and if you are signed in to Google Talk, their online status as well as their first-labeled number will appear under their name.



Browse through your contacts by rolling the trackball or by sliding your fingertip up and down on the screen. Rapid brush movements with your fingertip in either direction accelerate the scrolling. Touch the screen to stop the scrolling.

TIP: To find a contact quickly from the Home screen, open the keyboard and start typing their name. Your contact list appears and resolves to the letters you have typed.

9.1 Add contacts

1. From anywhere on your phone, press the green **Send** key.
2. Touch the Contacts tab.
3. Press the **Menu** key.
4. Touch **New** contact..
5. Type the contact's information.
6. Press the **Menu** key.
7. Touch **Save**.

9.2 Display contacts


To select which contact group to display in Contacts, press the Menu key and touch display group. You can select from the following:

- All contacts to displays every contact you have created or that has been added automatically.
- Contacts with phone numbers to display only contacts with phone numbers, regardless of whether you have created them on the phone or Web.
- My contacts to display a group created automatically based on those contacts you communicate with most frequently.

10 Gmail setup


Your phone can receive messages from your Gmail account.

By signing in to your phone, you are automatically set up to receive e-mail messages, and there are no additional steps needed to set up Gmail on your phone.





11 Email setup

Your phone can receive messages from your POP3 and IMAP e-mail accounts. You can fetch messages from up to five e-mail accounts.



11.1 Add e-mail accounts

1. On the Home screen, touch the application  button.
2. Touch Email. The Email setup screen appears guiding you through the setup process.
3. Touch **Next**.
4. Type your e-mail address and password to your e-mail account.
5. Touch **Next**.




The application will automatically configure the settings for many common e-mail services. Before you go


to your Inbox, you can name the account (if you don't, your e-mail address will be used). You are also asked to type your name as you want it to display on outgoing messages. You must complete this field before you can tap **Next** and go to your Inbox.

If your account is not automatically configured, follow the prompts to type the e-mail server, protocol, and other account information yourself. After your account settings have been verified, touch **Next** to go to your Inbox.

11.2 Delete e-mail accounts

You can always remove a POP3 or IMAP e-mail account from your phone. To delete:

1. On the Home screen, touch the application  button.
2. Touch Email.
3. Go to your Inbox.
4. Press the **Menu** key.
5. Touch **accounts**.
6. Touch and hold the account you want to delete.
7. Touch **Remove account**.
8. Touch **OK** to remove.



12 Bluetooth setup


Your phone comes with Bluetooth technology, which is a wireless technology that enables a data connection between your phone and a Bluetooth wireless headset.

12.1 Prepare a Bluetooth wireless headset

To pair your phone with a Bluetooth headset, make sure that your headset is fully charged and that you put the headset into pairing mode. See your Bluetooth headset's manual for more information.

12.2 Turn on the Bluetooth feature and pair with a headset


1. On the Home screen, press the Menu key.
2. Touch **Settings**.
3. Touch **Wireless controls**.
4. Touch **Bluetooth** to turn it on.
5. Touch **Bluetooth settings**. Your phone scans for available Bluetooth devices.
6. Touch the headset to select it.
7. Slide open the display to reveal the keyboard and type the PIN if needed.
8. Touch **OK**.



13 WI-FI

Your phone can connect to WI-FI networks. To connect:

1. On the Home screen, press the **Menu** key.
2. Touch **Settings**.
3. Touch **Wireless controls**.
4. Touch **WI-FI** to turn it on.
5. Touch **WI-FI settings**. Your phone scans for available WI-FI networks.
6. Touch the WI-FI network that you want to connect to.
7. Touch **Connect**.



14 Emergency dialing

While all phones are equipped with 112 emergency calling, this phone may or may not permit its location to be approximated during 112 call.

15 Update

When the system updates, we will update the upgrade packages in our website, you can download the latest version.

- 1、Download 'update.zip' to SD card, or Copy it to the root directory in SD card;
- 2、Press **Power** and **Back** simultaneously to enter **Recovery mode**;
- 3、Selected '**apply sdcard:update.zip**' with trackball, press it to start;
- 4、Upgrade complete successfully will be prompted to "install from sdcard complete". Select "reboot system now" re-enter to your phone with a new version.

Note: You can also directly contact our after-sales technical staff for system upgrades.

16 Caring for your phone

16.1 Making it last

Your phone is a complex electronic device; think of it as a mini-computer. Here are some hints that should help you extend the life of your new phone.

Phones aren't cheap, so keep yours in a safe place — away from children who may find it fun to see if the phone sinks or floats, and away from dogs that find plastic-coated products to be irresistible chew toys.

Water will damage your phone and accessories — even a small amount such as water droplets from a soda in your car cup-holder, melting snowflakes, tears of joy, squirt-gun crossfire or steam from hot water in the kitchen or bathroom.

Use only batteries and accessories from the original manufacturer of your phone. Non-approved accessories can cause damage to you or your phone and shorten the phone's life. Hint: If it's being sold out of someone's car trunk, walk away. If your charger or any other accessory is damaged, replace it or take it to a qualified service dealer. Do not attempt to operate your phone charger if it has received a sharp blow, been dropped, thrown from a speeding motorcycle or is otherwise damaged; doing so may damage your phone.


16.2 Tips for safety

Check with your doctor if you have a pacemaker or hearing aid in order to ensure that cell phone usage is safe with your device. If you have questions about the interaction of cellular radio frequency and any other electronic equipment, ask the manufacturer of the equipment if cell phone radio frequencies will disrupt the equipment's performance.

When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner.


Here are a few tips:

- Assess road conditions before answering. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone option before you start moving.
- Keep your phone closed. If it rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.
- Program frequently used numbers into your speed dial for easy one-touch dialing.
- Remember that laws prohibiting or restricting the use of a mobile phone while driving may apply in your area.



A1 User Manual

----Having fun



A1 User Manual	15
1 Gmail	16
1.1 Read new messages	17
1.2 Write new messages	17
2 E-mail	18
2.1 Read e-mail messages	18
2.2 Send e-mail messages	18
3 Picture Messaging	19
3.1 Send Picture Messages	19
4 Text Messaging	20
4.1 Read text messages	20
4.2 Send text messages	20
5 Instant messaging	21
5.1 Access Google Talk	21
5.2 Access other instant messaging accounts	21
6 Memory Card	21
6.1 Copy files to the memory card	22
6.2 Delete files on the memory card	23
6.3 View available memory space	23
7 Music	23
7.1 Access and play music	24
7.2 Add songs to new play list	25
7.3 Delete play lists	25
8 Gallery	25
8.1 Open Gallery	26
8.2 Close Gallery	26
9 Web Browsing	28
9.1 Go to your home page	28
9.2 Change your home page	28
9.3 Visit Web pages	28
10 Maps	29
10.1 Find a location	29
10.2 Get direction	29
10.3 Change map mode	29
11 Android Market	30
11.1 Browse contents	30
11.2 Install contents	30
12 Accessories of your phone	31


1 Gmail

With Gmail, all your messages on the same subject are threaded together into conversations. To read the messages in a conversation, open the conversation and scroll through the individual messages. The most recent message appears at the bottom.


All the Gmail that you fetch to your phone is delivered to your Inbox, and the Inbox is your default Gmail view. The total number of unread messages displays in the title bar and individual unread messages display in bold. If you have labeled a message, its label appears in a colored rectangle to the left of the date.



1.1 Read new messages

1. On the Home screen, touch the **Application**  **button.**
2. Touch **Gmail** to display your Inbox.
3. Touch a message to read.

1.2 Write new messages

1. On the Home screen, touch the **Application**  **button.**



2. Touch **Gmail** to display your Inbox.
3. Press the **Menu key**.
4. Touch **Compose**.
5. Type a name or e-mail address in the **To** field.

Matching contacts will appear. Select the contact

or continue typing.

6. Type the subject and message.
7. To attach pictures, press the **Menu** key and touch the picture to attach.
8. Touch **Send**.




2 E-mail

Your phone can receive messages from your POP3 and IMAP e-mail accounts.


You can fetch messages from up to five e-mail accounts.

For information on how to set up your e-mail, please see “E-mail Setup” in the **Getting Started** section.

2.1 Read e-mail messages

1. On the Home screen, touch the Application  button.
2. Touch Email to display your Inbox.
3. Touch the message to open.

2.2 Send e-mail messages

1. On the Home screen, touch the Application  button.
2. Touch Email to display your Inbox.
3. Press the **Menu** key.
4. Touch **Compose**.
5. Type a name or e-mail address in the To field.

Matching contacts will appear.

Select the contact or continue typing.


6. Type the subject and message.
7. To attach pictures, press the **Menu** key.
8. Touch the picture to attach.
9. Touch **Send**.


If you have more than one account and want to send an e-mail from a specific account, touch that account name before you press the Menu key and touch Compose.

3 Picture Messaging


3.1 Send Picture Messages

Pictures taken with the camera are stored on the memory card. Make sure the memory card is in the phone before you use the camera.

1. On the Home screen, touch the Application  button.
2. Touch Messaging.
3. Touch **New** message.
4. Press the **Menu** key.
5. Touch **Attach**.
6. Touch one of the following options:
 - Pictures to send a picture you have already taken. Touch the picture that you want to attach.
 - Camera to take a new picture and send. Frame the subject and press the Camera key on the side of the phone. Touch Select this photo.
 - Audio to attach one of the preloaded




To access pictures, go to the Pictures folder on the Application list.



audio files. Touch the file you want to attach and touch **OK**.

- Record audio to record and send an audio message. Touch the Record button to record and touch the Stop button stop. Touch Use this recording.
- Slideshow to attach multiple pictures and text. Touch Slide 1. Touch Add picture. Touch the picture that you want to add. Touch **Done**.




Record button

Stop button


- At the To field, start typing the phone number. Your contacts list appears.
- Touch the desired contact or continue typing the phone number.
- Touch the text entry field and type your message.
- Touch **Send**.


4 Text Messaging




With text messaging, all your messages on the same subject are threaded together into conversations. The inbox includes picture and text messages.

4.1 Read text messages

- On the Home screen, touch the Application  button.
- Touch Messaging.
- Touch the message to open.



4.2 Send text messages


1. On the Home screen, touch the Application  button
2. Touch Messaging.
3. Touch **New** message.
4. At the To field, start typing the phone number. Your contacts list appears.
5. Touch the desired contact or keep continuing typing the phone number.
6. Touch the text entry field and type your message.
7. Touch **Send**.


5 Instant messaging

5.1 Access Google Talk


You can use Google Talk to send instant messages to your friends. All you need is a Gmail account (you already have one).

To open Google Talk:

1. On the Home screen, touch the Application  button.
2. Touch IM.
3. Touch Google Talk account to launch. The Friends list appears.
4. Press the **Menu** key to add friends, block, and invite.




Top Wise limited. Company, Shenzhen



All right reserved.

5.2 Access other instant messaging accounts

1. On the Home screen, touch the Application  button.
2. Touch IM.
3. Touch AIM, Windows Live Messenger, or Yahoo! Messenger.
5. Sign in with your username and password.

6 Memory Card

6.1 Copy files to the memory card

You can transfer files such as music and pictures between your phone and your computer.

To view files on your phone, just launch the appropriate application and navigate to the file within that application.

Set phone to mass storage setting

Before you can transfer files, you must first set your phone to mass storage mode. To set:

1. Connect your phone to your computer using the USB cable.
2. On the Home screen, press the **Menu** key.
3. Touch **Settings**.
4. Touch **SD card & phone storage**.
5. Touch **Use for USB storage**.

If you enable “Use for USB storage,” you will not be able to access your pictures or music via the applications on your phone while your phone is connected to the USB cable. To access pictures or music on your phone,

simply disconnect the cable.


Copy files to the memory card

1. Connect your phone to your computer using the USB cable.
2. If needed, click Open folder to view files and click **OK**.
3. On your computer, go to the Removable Disk folder.
4. Locate the files on the computer that you want to copy to your phone.
5. Copy and paste files to the desired location in the Removable Disk folder.

If you organize your pictures into folders, each folder will display as an album in the Pictures folder on your phone.

6.2 Delete files on the memory card

1. Locate the file that you want to delete.
2. Touch and hold the file name.
3. Touch **Delete**.



6.3 View available memory space


1. On the Home screen, press the **Menu** key.
2. Touch **Settings**.
3. Touch **SD card & phone storage** to view available memory space for your memory card and phone.

7 Music

Your music is organized into four categories: Artists, Albums, Songs, and Play lists. Select a category to view the lists within each. Once in a category, keep selecting until you reach the music you want to play. For example, if you select the Artists category, you will see a list of artists in A–Z order. If you select an artist, the list opens to display that artist's albums. Select an album, and the album's song list displays.

Your phone will play the following music file formats:

- MP3
- M4A (iTunes AAC, DRM-free)
- AMR
- WMA (8)
- MIDI
- WAV
- OGG Vorbis



Playback controls

Touch to pause; to resume play.


Touch & hold .


Touch once.

Touch & hold .

Touch once.


7.1 Access and play music

1. On the Home screen, touch the Application  button.
2. Touch Music.
3. Touch Songs. You can also touch Artists, Albums, or Play lists.
4. Touch the song to play.




7.2 Add songs to new play list

1. On the Home screen, touch the Application  button.
2. Touch Music.
3. Touch Songs.
4. Touch and hold the song that you want to add to the play list.
5. Touch **Add to play list**.
6. Touch **New**.
7. Type the name for the play list.
8. Touch **Save**.



You can easily add a song as your ring tone. Touch and hold the song and then select Use as phone ring tone.

7.3 Delete play lists


1. On the Home screen, touch the Application  button.


2. Touch Music.
3. Touch Play list.
4. Touch and hold the play list you want to delete.
5. Touch **Delete**.

8 Gallery

You can view pictures, photos and video in Gallery. You also can do basic picture editing, Such as cutting, save as wallpaper or contact pictures, and share with your friends.

8.1 Open Gallery

1. On the Home screen, touch the Application  button.
2. Touch Gallery.
3. Select documents which you want.




Note: Because of the number of the files, it may take some time to load all the pictures.

8.2 Close Gallery

Touch **Back** menu to close the gallery in picture preview interface.

Note: If you come into Gallery from Camera, Touch **Back** menu to the Camera.



Enlarge photo of local shows

Double-click to zoom your part. it can be reduced once again when you double-click.

9 Web Browsing


9.1 Go to your home page


The Browser always opens to the last Web page you were viewing.

The first time you enter the Browser after powering on, your home page will display.


1. On the Home screen, touch the Application  button.

9.2 Change your home page

1. On the Home screen, touch the Application  button.
2. Touch Browser.
3. Press the **Menu** key.
4. Touch **More**.
5. Touch **Settings**.
6. Touch **Set home page**.
7. Type the site address and touch **OK**.




9.3 Visit Web pages


1. On the Home screen, touch the Application  button.
2. Touch Browser.
3. Press the **Menu** key.
4. Touch **Go to URL**.
5. Type the Web address.
6. Touch **Go**.




10 Maps

10.1 Find a location

1. On the Home screen, touch the Application  button.
2. Touch Maps.
3. Press the **Menu** key.
4. Touch **Search**.
5. Type an address.
6. Touch **Search**.
7. Touch Show map to see the result on a map.




10.2 Get direction



1. On the Home screen, touch the Application  button.
2. Touch Maps.
3. Press the **Menu** key.
4. Touch **Directions**.
5. At the From field, type your starting address.
6. At the To field, type your destination address.
7. Touch **Route**.

10.3 Change map mode

Google Maps gives you both map and satellite views of the area you are viewing.
To view satellite, traffic, or street view:

1. On the Home screen, touch the Application  button.
2. Touch Maps.
3. Press the **Menu** key.

- 4. Touch Map mode.
- 5. Touch Satellite, Traffic, or Street View.



11 Android Market


Android Market™ provides you with direct access to software developers throughout the world. It is the place to go to find fun games and cool applications.


11.1 Browse contents

When you first enter Android Market, you will see featured items, a list of item categories, a link to search, and a link to My downloads.

Scroll through the featured items or select a category to browse its contents, then select a subcategory. Within each subcategory you can select to view items sorted by popularity or by date. Note that all items in a subcategory are listed in each tab; those in the By popularity tab are sorted most popular to least popular, and those in the By date tab are sorted newest to oldest.

To access:

1. On the Home screen, touch the Application  button.
2. Touch Market.



11.2 Install contents

1. On the Home screen, touch the Application
2. Touch Market.
3. Navigate to and select the item you want to install.

The Item details screen appears. Read more about the item on this screen, including its overall rating and comments by users. If you scroll down to the About the developer section, you can view more applications by this developer or send the developer an e-mail message.

4. Touch Install (if free) or Buy.
 - After selecting Install, the item will start downloading immediately.
 - After selecting Buy, you may be asked to sign in to an additional Google account. Sign in and select Purchase now if you want to proceed. Step through the purchase screens.

Important! If an application requires either access to any of your data or control of any functions on your phone, before you proceed, you will see a screen telling you what the application can access so you can give your permission. Be sure to read this carefully! Be especially cautious if an application has access to many functions or a significant amount of your data. Once you touch OK on this screen, you will be responsible for the results of using this item on your phone.

All support for Market applications is provided by the developer of that application. The developer information is available on the detail page for each application.

12 Accessories of your phone

Whether you're looking for a charger, a fashionable carrying case, a Bluetooth® headset, or just want to browse for fun extras for your phone, Contact with your mobile phone manufacturers.